

Installation Manual

DC/DC converters

PSC300, PSC400, PSC600, PSC700, PSC800



PSC600 for 6HE 8TE mounting



PSC600 wall/chassis mounting option N



Connector assembly option N,
with optional H15 screw
connection females and
connector holders.



Schulz-Electronic GmbH
Dr.-Rudolf-Eberle-Straße 2
D-76534 Baden-Baden
Fon +49.7223.9636.0
Fax +49.7223.9636.90
vertrieb@schulz-electronic.de
www.schulz-electronic.de

Polyamp AB
Box 925
191 29 SOLLENTUNA
Sweden

www.polyamp.com
info@polyamp.se
Tel: +46 859469300
Tel: +46 859469305

EU VAT no SE556103276301
DUNS no 35-430-3372
CAGE S4231
NCAGE S4231

Warranty

All Polyamp DC/DC converters are warranted against defective material and workmanship. This warranty is valid for 24 months from the date of delivery.

We will repair or replace products which prove to be defective during the warranty period. The warranty is valid only if the converter is used within specification.

Manual

This manual is as complete and actual as possible at the time of printing. However, the information may have been updated since then. Polyamp AB reserves the right to make changes in this manual without notice.



The exclamation point within an equilateral triangle is intended to alert the user to presence of important operating and maintenance instructions in the literature accompanying



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to presence of un-insulated "dangerous voltage" within the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons

Caution!

To prevent the risk of electric shock, do not open enclosure. No serviceable parts inside. Refer servicing to qualified service personnel only



We supply a separate declaration of conformity within our shipment that mainly refers to the Low voltage directive and EMC directive.



INSTALLATION MANUAL
PSC600 series

1	Before installation	4
1.1	Cable and pin dimensioning.....	4
1.2	Reverse polarity protection.....	4
1.3	Input fuse	5
1.4	Inrush current limit	5
2	Installation.....	5
3	Parallel connection	7
3.1	Series diode on the output, option C.....	7
3.2	Series diode with series resistor, option CR	7
3.3	Output under voltage alarm	7
3.4	Connecting systems in N+1 configuration.....	7
3.5	Connecting converters in parallel on the output	8
3.6	Adjusting output voltage when units are paralleled on the output.....	8
5	Multiple loads at the output.....	9
5.1	Short-circuits.....	9
6	Output voltage sense, option S.....	10
7	Output over voltage protection OVP.....	10
7.1	Standard feature	10
7.2	OVP option A	10
8	Under voltage Alarm relay	10
9	Higher isolation voltage, Option E1 & E2	11
10	Insulation voltage test.....	11
10.1	DC isolation test output to case.....	11
10.2	AC isolation test output to case, option E2	11
10.3	DC isolation test input to output and input to case	12
10.4	AC isolation test input to output and input to case	12
11	Trouble shooting	13
11.1	There is no or wrong output voltage	13
11.2	The input fuse blows when the input is connected.....	13
11.3	The converter starts and stops repeatedly	13
11.4	Fault report	13

1 Before installation

Before installation, please read this section and minimum section 2. This installation manual shall also be read together with the datasheet of the product. Download the datasheet from www.polyamp.com and check the File archive where in section Datasheet you will find PSC600.pdf.

If any problem occurs during installation please check *section 11 Trouble shooting*. This product family is called PSC600.

The product is labelled as below example:

<p>PSC600 110/24 Input: 110Vd.c.: 6 A; Input range: 88 – 150 Vd.c. Output: 24V 25A Option: L, C</p>

The DC/DC converter type name consists of model name PSC300, PSC400, PSC600, PSC700 and PSC800 followed by input code and output voltage. Two examples:

- **”Type: PSC600 24/48”** has input code **”24”** and nominal output voltage **48 Vd.c.** The 600 indicates around 600 W output power.
- **”Type: PSC800 110/24”** has input code **”110”** and nominal output voltage **24 Vd.c.** The 800 indicates around 800 W output power.

The **Options** are block letters separated by comma(.). You will find explanation within this manual what the letter code means.

The **input** states the nominal input voltage and **maximum input current** at any conditions. It means the output is adjusted +10% above nominal voltage and close to the current limit, which is the stated output current +5% and a lowest input voltage level.

Input range is the input range that the unit can operate normally.

Output indicates the nominal output voltage and the rated current.

The output is current limited with a so called rectangular characteristic. When the current limit is reached, which is adjusted to +5% of above mentioned nominal output current, this is the maximum current that will continuously flow. The output voltage drops very quickly down towards zero volt (depends on the series resistance of the load circuit as the unit can be regarded as a constant current generator at over current condition). We have no time limit on over current condition.

Temperature range is the rated operation temperature at 100% load condition.

Input, output and case are galvanically separated from each other. This is a **Class I Insulation system**, which is dependent of correct earth connection on the input. All outputs are insulated from case with minimum 2000 Vd.c. *Section 10 Insulation voltage test*, describes the insulation rating depending on input voltage. See *section 9* if higher insulation is required.

Series number is stamped on the panel under the connector

1.1 Cable and pin dimensioning

The PSC600 series is using two DIN 41621 H15 connectors intended for 6HE Euro format mounting. Each pin has a continuous current rating of 15A @+55°C and 12A @+70°C ambient temperature.

All pins in one pole are parallel connected internally, *see Figure 1*. Therefore on C, D, 110, and 220 inputs only one input pin per pole needs to be used. It is also possible to supply 6 different outputs/loads or use a limited number of pins depending on the output current. E.g. 24V 25A only need two pins.

1.2 Reverse polarity protection

The input is protected from reverse polarity. The method used is dependent of the input.

On A, B, 24, 36 input a parallel diode is used that is dimensioned to blow an external fuse.

On C, D, 48, 72, 110, 220 input a series diode is provided. The converter will not start if reverse voltage is applied.

It is possible to use series diode on input A, B, 24, 36 with derated performances due to higher power losses.

Please contact your local distributor or factory, for more information.

1.3 Input fuse

The input should be fused with an approved fuse with a slow blow characteristic and high breaking capacity. Select a stand current rating equal or above the below specified value, see *Table 1 to 3*.

Input voltage code	Slow blow fuse PSC400
A	46 A
B	23 A
C	10 A
D	5 A

Table 1. Recommended input fuses.

Input voltage code	Slow blow fuse PSC400	Slow blow fuse PSC600	Slow blow fuse PSC800
24	25 A	37 A	63 A
48	13 A	19 A	25 A
110	5 A	7.5 A	12 A
220	2.5 A	3.7 A	6 A

Table 2. Recommended input fuses.

Input voltage code	Slow blow fuse PSC400	Slow blow fuse PSC600	Slow blow fuse PSC800
24T	31 A	47 A	63 A
36T	25 A	35 A	50 A
48T	16 A	24 A	35 A
72T	12.5	16 A	25 A
110T	7 A	10 A	15 A

Table 3. Recommended input fuses.

There are two reasons we do not include an input fuse:

1. DC-networks should be fused at the distribution point to protect the cable.
2. Different applications require different types of fuses.

A switching device able to switch off both polarities input cables has to be mounted externally. The switching device shall be

marked accordingly and easy accessible. If the converter is mounted in an electric vehicle, an external series diode on the input is recommended. Please contact your Polyamp dealer.

1.4 Inrush current limit

The input capacitors are charged through an active inrush current limit circuit that reduces the input inrush current during start up. This feature is standard on the PC600 series with input codes C, D and 48, 72, 110, 220.

For B and 24, 36 input codes the inrush current limit circuit is optional. On those this circuit will affect the input voltage range and the output power due to voltage drop losses in combination with high input currents.

All models has an "output soft start" that do not increase the input current above the unit rated current during start up (approx.. 0.1s).

2 Installation

The converter is designed to be mounted in a 6HE 19" sub rack unit, in such case the L-version must be ordered.

The PSC600 version with N mounting, a location only accessible for service, which meets the demand of EN60950 regarding fire enclosure, voltage hazard protection and mechanical strength, shall be used.

With option N, wall mounting set you can mount the converter in any direction on a wall or with optional mounting clips on DIN rail TS35. The converter is convection cooled and in order to get sufficient cooling there shall be a free air around the converter. If this is not possible, we recommend the use of an external fan.

Note that the expected life of the converter is dependent on converter temperature. For every 10°C that the temperature is lowered the expected life is approximately doubled. It is therefore crucial to cater for good ventilation and if possible to reduce ambient temperature.

To meet the EMC specifications in the enclosed "declaration of conformity" use

twisted-pairs for connecting input, output and alarm. Shielded cables are not necessary.

If the converter supplies a DC-motor, we recommend an external parallel diode at the motor poles to protect against reverse voltages.

Installation in a 6HE 19" Euro sub rack:

1. Check the pin-out, *see Figure 1*. Connect the protective earth pin 32 on the input connector. This provides safety against electrical shock and is required to achieve EMC performance according to the declaration of conformity.
2. Be aware that if the sense option "S" is provided the sense must be connected to the sensing point of the output and cannot be left open. *See section 6*.
3. Plug in the unit. Go to point 3 below.




Figure 1. Pin-out on OUTPUT and INPUT DIN41612 H15 connectors.

Installation with wall mounting panel option N:

1. Check the pin-out, *see Figure 1*. Connect the protective earth pin 32 on the input connector. On bolt/studs connector models the protective earth is a separate screw. Protective earth provides safety against electrical shock and is required to achieve EMC

performance according to the declaration of conformity.

2. Connect the output. Be aware that if the sense option "S" is provided the sense must be connected to the sensing point of the output and cannot be left open. *See section 6*. Bundle the output cables together, separate from input.
3. The converter output is short-circuit proof by a constant current limit which works unlimited in time. Therefore there is no need to fuse the load (unless you use multiple loads, see below). The current limit is fixed to 105% of nominal output current.
4. Features and options
 - If the converter is to be connected in parallel at the output, please *consult page 7*.
 - If you use multiple loads, please *consult section 5 Multiple loads at the output on page 9*.
 - If you intend to use alarm feature, please *consult Under voltage Alarm on page 10*.
 - The output have an over voltage limit circuit that is set +15% of nominal output. *See also section 8 OVP option, page 10*.
5. Connect the input cables. Bundle input cables together separated from the output cables.
6. Start the converter by inserting your input slow blow fuse to your DC voltage supply. Sparks may occur when the input capacitors are charging.

Beware of hazardous voltages!

The output voltage can be adjusted $\pm 10\%$ of the nominal output voltage with the potentiometer marked V.ADJ on the front panel. Clockwise turn increases the output voltage. The potentiometer has 15 turns. If you have connected units in parallel on the output, the procedure of adjusting the output voltage is described in *section 3.6 Adjusting output voltage when units are paralleled on the output on page 8*.

3 Parallel connection

If a redundant power supply system is requested, two or more converters can be connected in parallel. To achieve redundancy the number of converters must be dimensioned to carry the whole load even if one converter is faulty. The option C or CR series diode on the output must be provided. Connect your load to the + output after the series diode (cathode).

Another reason for connecting two or more converters in parallel is to get more power. The option C must be provided. When the series diode C or CR option is used the *Sense option S*, see section 6 page 10, cannot be used.

3.1 Series diode on the output, option C

A series diode is necessary if the output is connected in parallel with another power supply or if you require redundant operation. If a converter breaks down with an internal short-circuit on the output and other converters are connected in parallel on the output, the broken unit will short-circuit the others if the series diode is not used. This might cause excessive heat or even fire in the faulty unit. The series diode protects the converter output from external voltage sources.

3.2 Series diode with series resistor, option CR

This option is an extension of 3.1 Series diode. When several PSC600 units are connected in parallel with so called "hot plug in" in 19" sub-rack, a built in series resistor and series diode is provided that will automatically balance the current between units.

The series resistor will provide the Ud function described in section 3.4 and figure 45. Thus no special cable arrangements are needed with this CR option.

3.3 Output under voltage alarm

If one DC/DC converter fails in a redundant power system an alarm signal should be detected.

The PSC600 has relay output as a standard feature, see section 8.

3.4 Connecting systems in N+1 configuration




Figure 2. An N+1 system with two units for the load and one for the redundancy.

The Figure 2 shows an N+1 system with two units for the load and one for the redundancy. Each DC/DC converter has a built in; series diode (C), balancing resistor (R) and alarm relay outputs. The alarm is cascade connected. Note that each DC/DC converter has individual external input fuses.

With the CR option a hot plug-in can be achieved if the output voltage is correctly adjusted. Use instruction in section 3.6 -3 below.

3.5 Connecting converters in parallel on the output

The expected life of the converter is dependent on converter temperature. It is therefore important for paralleled unit to share the load as equal as possible to reduce the converter temperature. To achieve good current sharing the converters must have separate cables to the load. The cables should be dimensioned to have a voltage drop, U_d , between the converter and the load at maximum current capacity, see *Figure 3 and Figure 4*.

- When the series diode is used, which we recommend, the voltage drop should be approximately 1.0% of nominal output voltage (to also compensate for the negative temperature coefficient of the diode).
- When the series diode is **not** used, **this is not recommended**, the voltage drop should be approximately 0.5% of nominal output voltage.




Figure 3. Parallel connection, with optional capacitor.




Figure 4. Load regulation with voltage drop U_d between output and load

Note that the voltage drop affects the load regulation (the voltage at the load), see *Figure 4*.

3.6 Adjusting output voltage when units are paralleled on the output

1. Connect and start all converters according to *Installation on page 6*. We recommend using the series diode and separate cables as mentioned above in *3.5 Connecting converters in parallel on the output* or the *CR option 3.2*.
2. Measure the voltage at the load. Connect voltmeters as showed in *Figure 5*. If you have only access to one voltmeter you must move it around to make the adjustments.




Figure 5. Adjusting output voltage measure at +Test or pin 8 on the H15 connector.

3. To **increase** the output voltage. Increase the output voltage by turning the potentiometer marked "V.ADJ" clockwise on the unit with the lowest output voltage until you reach the desired voltage at the load or until the output voltage does not increase anymore (as the unit is in current limit). To find the unit with the lowest output voltage you can measure the voltage difference before the series diode, as in *Figure 5*. Repeat from i. until you reach the desired output voltage at the load.
4. To **decrease** the output voltage.
 - i. Decrease the output voltage by turning the potentiometer marked "V.ADJ" counter clockwise on the unit with the highest output voltage until you reach

the desired voltage at the load or until the output voltage does not decrease anymore (as the other units supply all current). To find the unit with the highest output voltage, measure the voltage difference before the series diode, as in *Figure 5*.

- ii. Repeat from i. until you reach the desired output voltage at the load.
5. To achieve good current sharing, adjust all converters so that the voltage difference before the series diode is 0.00 V between all units that are connected in parallel and so that the voltage at the load is still the desired.

5 Multiple loads at the output

If you are using several loads, we recommend fusing them separately with fast acting fuses. Some considerations regarding short-circuits should be taken.




Figure 6. Connecting multiple loads.

5.1 Short-circuits

1. If there is a short circuit in one branch and the total current in all branches **does not exceed 105%** of the nominal current of the converter (see label on front panel), the output voltage will not be affected. The time for the fuse to blow can be calculated from the data sheet of the fuse if you know the short circuit current through the fuse.
2. If there is a short circuit in one branch and the total current in all branches **does exceed 105%** of the nominal current of the converter, the output voltage will drop until the fuse is blown. Depending on the impedance of the short circuit (whether it is abrupt or merely an overload) and the resistance of the load cables, the effects of a short circuit will vary.

Long cables reduce short-circuit currents, resulting in longer delay until the fuse is blown and hence an increased voltage dip. Light overload does not necessarily result in a blown fuse.

To reduce the voltage drop at short-circuit and if any branch has more than approximately 30% of the total output current of the converter, a large external capacitor is recommended. Such a capacitor will supply the peak current needed to blow the fuse, see *Figure 6*. To calculate the capacitor needed, use the following formula:

$$C = 1.2 \times (IS \times \Delta t) / \Delta U$$

1.2 = Safety margin.

IS = Short-circuit current through the fuse.

Δt = Time before the fuse blows (see data sheet on the fuse).

ΔU = Acceptable voltage dip before the fuse blows.

Example:

You have a 1A fuse with fast characteristic and the short-circuit current is 10A. The data sheet gives you that $\Delta t = 10\text{ms}$. The output voltage is 24V, and you can accept 10% voltage drop $\Rightarrow \Delta U = 24 \times 0.1 = 2.4\text{V}$.

The capacitance you need:

$$C = 1.2 \times (IS \times \Delta t) / \Delta U = 1.2 \times 10 \times 0.01 / 2.4 = 50,000\mu\text{F}$$

Choose a capacitance with a rated voltage of at least 115% of nominal output voltage of the converter.

Repeat this calculation for all branches and choose the highest capacitance value.

It is sometimes difficult to estimate the short-circuit current when the nature of a fault is unknown. In this case a voltage dip might appear under some short-circuit conditions even with a large capacitor present. If a voltage dip is critical in one branch it is recommended to use a separate DC/DC converter supplying this branch.

6 Output voltage sense, option S.

The remote voltage sense is used to improve the regulation at the load. The voltage regulation is moved to a point outside the converter where the sense is connected. Longer sense leads than 3 m is not recommended. The voltage difference between the load and the converter should not be larger than the output voltage range. Use twisted sense wires, see Figure 7.

The sense leads must always be connected to respective pole, even if not used externally. The sense cannot be used in a paralleled system, described in section 3.




Figure 7. Remote sense connection.

7 Output over voltage protection OVP

7.1 Standard feature

In case the regulation circuit fails on the output, a secondary regulation circuit limit the output voltage level. The circuit also protects the converter output from external voltages. The trigger voltage is set to 115% to 120% of the nominal voltage. The circuit is active as long as the over voltage condition remains.

7.2 OVP option A

An independent circuit using a SCR thyristor is used as over voltage protection. When activated it short circuits the output. Reset a triggered OVP by switching off and on the input voltage.

The circuit protects the converter from high external voltages as well as regulation failures of the unit. The OVP trigger voltage is set to 115% to 120% of the nominal voltage. OVP is standard on all 5 V master outputs and will trigger at max. 6.2 V.

8 Under voltage Alarm relay

The alarm has dry contact output with selectable NO, NC function. The relay output is insulated from both input and output 2.5 kVa.c., see Figure 10.

The relay is rated 30V 0.5A (a.c. & d.c.).

For higher voltage/current relay rating please contact Polyamp.

On versions for 6HE 19"-subrack mounting option L the alarm is transferred to pin 16 and 18 and have a NC function.

The alarm relay can be connected in two ways:

1. Normally Open (NO). Connect twisted-pair (0.25 mm² - 0.5 mm²) from centre pin of the removable alarm connector and connector pin marked "NO".
2. Normally Closed (NC). Connect twisted-pair (0.25 mm² - 0.5 mm²) from centre pin of the removable alarm connector and connector pin marked "NC".




Figure 8. UL alarm with internal relay. Relay symbol shows Alarm state.

9 Higher isolation voltage, Option E1 & E2

E1 is 2 to 2.5 kVa.c. 1 minute between input and output, input and case. The emission level is increase to level A.
On PSC600 series with input ranges from 110 to 220 and C, D input ranges this is a standard feature.

E2 is 2 to 2.5 kVa.c. 1 minute between output and case. The emission level is increase to level A.

10 Insulation voltage test

Each converter has been isolation tested in factory before delivery. Please note that consecutive insulation test damage the Y-capacitors and affect the EMC performance of the unit. We ask you therefore to minimize or completely avoid such test.

The insulation voltage is 2.5 kVa.c between input and output, input and case. The output to case isolation is 2 kVd.c. on all models. Option E2 can increase this isolation.

If your isolation test equipment cannot supply the AC current, you can perform a DC isolation test with 4000 Vd.c ($2500\text{ V} \times \sqrt{2} \times 1.1 \approx 4000\text{ Vd.c}$ where 1.1 = safety factor).

10.1 DC isolation test output to case

1. Disconnect all cables from the converter.
2. Connect the input terminals of the converter to case.
3. Connect the output terminals together.
4. Connect your isolation tester between output and case. See *Figure 9*.




Figure 9. Output to case isolation voltage test.



An insulation test shall only be performed by personnel aware of the dangers and hazards of the test.

5. Raise the voltage of the isolation tester from 0 to 2000 Vd.c. (With option E2 0 to 4000 Vd.c.) Check that the leakage current does not exceed 5 μA . The voltage should not be applied for more than a few seconds or the Y-capacitors might be damaged.
6. Turn off the isolation tester and discharge the test voltage with a 10 M Ω resistor between output and case.

10.2 AC isolation test output to case, option E2

Beware of the rather high capacitive earth currents (about 100mA) that will occur during this test.

1. Disconnect all cables from the converter.
2. Connect the input terminals of the converter to case.
3. Connect the output terminals together.
4. Connect your isolation tester between output and case. See *Figure 9*.
5. Raise the voltage of the isolation tester from 0 to 2500 Va.c. The voltage should not be applied for more than one (1) minute or the Y-capacitors might be damaged.
6. Turn off the isolation tester and discharge the test voltage with a 10 M Ω resistor between output and case.



Warning!

An insulation test shall only be performed by personnel aware of the dangers and hazards of the test.




Figure 10. Input to output and input to case isolation voltage test.

10.3 DC isolation test input to output and input to case

1. Disconnect all cables from the converter.
2. Connect the output terminals of the converter to case. See *Figure 10*.
3. Connect the input terminals together.
4. Connect your isolation tester between input and case. See *Figure 10*.
5. Raise the voltage of the isolation tester from 0 to 4000 Vd.c. Check that the leakage current does not exceed $5\mu\text{A}$. The voltage should not be applied for more than a few seconds or the Y-capacitors might be damaged.
6. Turn off the isolation tester and discharge the test voltage with a $10\text{ M}\Omega$ resistor between input and case.

10.4 AC isolation test input to output and input to case

Beware of the rather high capacitive earth currents (about 100mA) that will occur during this test.

1. Disconnect all cables from the converter.
2. Connect the output terminals of the converter to case. See *Figure 10*.
3. Connect the input terminals together.
4. Connect your isolation tester between input and case. See *Figure 10* Raise the voltage of the isolation tester from 0 to 2500 Va.c. The voltage should not be applied for more than one (1) minute or the Y capacitors might be damaged.
5. Turn off the isolation tester and discharge the test voltage with a $10\text{ M}\Omega$ resistor between input and case.

11 Trouble shooting

11.1 There is no or wrong output voltage

- 1 Check that the input fuse is not broken.
- 2 Check that the input voltage polarity is correct.
- 3 Check that the input voltage is within the specified limits.
- 4 The converter may be in current limit due to excessive output current or an external short-circuit on the output.
 - Measure the output voltage. If shows > 0.5 V the thyristor OVP, *see section 7.2*, might have triggered.
 - Disconnect the input by removing the fuse.
 - Disconnect the load.
 - Connect input fuse again and measure the output voltage. If the converter now starts, the load is too high or there is a short circuit on the load side.
 - If there is an external short-circuit, remove it.
 - If the load is too large decrease the load or consult your Polyamp dealer.
- 5 The unit is broken. Contact your Polyamp dealer.

11.2 The input fuse blows when the input is connected

- 1 Check that the input voltage polarity is correct.
- 2 Check that the input fuse is of time delay type and with correct current rating. See *Table 1 to 3*.
- 3 The unit is broken. Contact your Polyamp dealer.

11.3 The converter starts and stops repeatedly

All models have an over/under voltage protection, which shuts down the converter if the input voltage is not within specified limits:

- 1 The cables to the converter input may be under-sized, causing too high voltage drop in the supply cables.

2. Your supply does not have enough current capacity so the input voltage to the converter drops below specified limit.

11.4 Fault report

We do not recommend you to repair a faulty unit. All unit opened by customer will not be repaired under warranty.

Please use our RMA system from our webpage www.polyamp.com

Warranty

All Polyamp DC/DC converters are warranted against defective material and workmanship. This warranty is valid for 24 months from the date of delivery. We will repair or replace products which prove to be defective during the warranty period. The warranty is valid only if the converter is used within specification.

Please describe the conditions when the fault occurred and please return a faulty converter to:

Your local distributor or:

**SWITCH CRAFT S.A.
Bel Air 63
CH-2300 La Chaux-de-Fonds
Switzerland**

**Tel: +41 32 9678800
Fax: +41 32 9678809
e-mail: info@switchcraft.ch**

**Latest version of this manual
www.polyamp.com**